

# Fort Worth, Texas 76140

### ASSEMBLY INSTRUCTIONS


### 1380 TREE HOUSE TWIN LOFT BED



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"





#### **IMPORTANT:**


PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY





**Identifying the Hardware**-Identify the hardware using the illustrations below.



























14





## Alignment

