

## #300B FUTON BODY WITH HINGES.

### SPECIAL INSTRUCTIONS FOR THE FUTON OPTION FOR THE LOWER BED. FOLLOW THESE INSTRUCTIONS.

- INSTALL THE BUNK BED SLAT KIT ON THE LOWER BED, ATTACH USING TWO SCREWS AT EACH END OF THE FIRST AND LAST SLAT, AND TWO SCREWS ON EACH END OF THE MIDDLE SLAT.
- INSTALL THE HINGE WITH BOLTS, WASHERS AND NUTS FOUND IN THE FUTON BOX HARDWARE, TO THE BOTTOM BOARD OF EACH END STRUCTURE. YOU WILL SEE TWO HOLES DRILLED ON THE BOTTOM CROSS BOARD OF THE HEAD BOARD. THE SPRING GOES TO THE REAR OF THE BED. PLACE THE WASHER BETWEEN BOLT AND WOOD ON THE OUTER SURFACE OF THE HEAD BOARD SECTION. USE CAUTION WHEN HANDLING THE HINGE MECHANISM.
- THE SEAT DECK HAS TWO "HANDLES" WHICH HOLD THE FUTON MATTESSES IN PLACE. THE TWO "HANDLES" GO TO FRONT OF THE LOWER BED SURFACE. THE BACK DECK DOES NOT HAVE THE "HANDLES",
- ATTACH BACK DECK TO HINGE WITH NUT, WASHER AND BOLT, PLACE WASHER BETWEEN BOLT HEAD AND TUBULAR METAL OF THE FUTON BODY. REPEAT FOR SEAT DECK (DECK WITH FRONT "HANDLES"). WHEN ALL BOLTS ARE INSTALLED, THEN FULLY TIGHTEN ALL BOLTS.
- THE FUTON BODY SHOULD BE OPENED AND CLOSED WHILE STANDING AT THE CENTER OF THE TWO HANDLES.



HOLES FOR HINGE  
ON HEAD BOARD

