



Model: 9070 PINK BUNK

SAFETY WARNINGS

1. Follow the information on the warnings appearing on the upper bunk end structure and on the carton. Do not remove warning label from bed
2. Always use the recommended size mattress or mattress support, or both, to help prevent the likelihood of entrapment or falls.
3. Surface of mattress must be at least 5 inches (127mm) below the upper edge of guardrails.
4. Do not allow children under 6 years of age to use the upper bunk
5. Prohibit more than one person on the upper bunk
6. Periodically, check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight
7. Do not allow horseplay on or under the bed and prohibit jumping on the bed
8. Always use the ladder for entering and leaving the upper bunk.
9. Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
10. Use of a nightlight may provide added safety precaution for a child using the upper bunk.
11. Always use guardrail on both long sides of the upper bunk. If bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
12. The use of water or sleep flotation mattresses is prohibited.
13. Keep these instructions for future reference.

STRANGULATION HAZARD

Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts and jump ropes.

SIZE OF MATTRESS AND FOUNDATION

Use only mattress which is 74" - 75" long and 37 1/2" - 38 1/2" wide on twin upper bunk

Use only mattress which is 74" - 75" long and 37 1/2" - 38 1/2" wide on twin lower bunk

Ensure thickness of mattress and foundation combined does not exceed 8" and mattress and is at least 5" below upper edge of guardrails.


Replacement parts, maybe obtained from any Donco dealer or directly from us at the below address.

6801 Snowden Road Fort
Worth, Texas 76140















PARTS LIST: DN9070

PINK BUNK BED

P.1/7



HARDWARE PACK #: DN9070



CODE	DESCRIPTION		DIMENSION	Q'TY
1	Dowel		Ø10x40mm	40 pcs
2	Bolt		(Ø12)1/4"*120mm	22 pcs
3	Bolt		(Ø12)1/4"*100mm	16 pcs
4	Bolt		(Ø12)1/4"*80mm	2 pcs
5	Bolt		(Ø12)1/4"*35mm	2 pcs
6	Bolt		(Ø12)1/4"*30mm	6 pcs
7	Allen Wrench		(1/4")4.5*58mm	1 pc
8	Half Moon Nuts		21*12*9mm	16 pcs
9	Wood Screw		(Ø12)1/4"*50mm	8 pcs
10	Metal Pin		Ø9*90mm	4 pcs
11	Wood Screw		Ø4*30mm	52 pcs
12	Wood Screw		Ø4*20mm	6 pcs
13	Hooks		81*26*21(2.5mm)	2 pcs
14	Foam Stick		90*17*2mm	2 pcs


ASSEMBLY INSTRUCTION: 9070

PINK BUNK BED

P.2/7




STEP 1


#1		x8
#2		x8



2PCS

STEP 2

#1		x4
#3		x8
#8		x8




ASSEMBLY INSTRUCTION: 9070

PINK BUNK BED



P.3/7


STEP 3

#11		x26
-----	---	-----



STEP 4

#1		x4
#2		x4






ASSEMBLY INSTRUCTION: 9070

PINK BUNK BED






P.4/7


STEP 5

#1		x4
#2		x4



STEP 6

#1		x6
#2		x4
#3		x4
#6		x3
#8		x4











ASSEMBLY INSTRUCTION: 9070

PINK BUNK BED


P.5/7


STEP 7

#1		x6
#2		x2
#3		x4
#4		x2
#5		x2
#6		x3
#8		x4



STEP 8

#11		x26
-----	---	-----





ASSEMBLY INSTRUCTION: 9070

PINK BUNK BED






P.6/7


STEP 9

#10		x4
-----	---	----



STEP 10

#1		x8
#9		x8
#12		x4
#13		x2
#14		x2



ASSEMBLY INSTRUCTION: 9070

PINK BUNK BED

P.7/7

STEP 11

#12		x2
-----	---	----

