


Bed Assembly Instructions

MODERN BED

Hardware Pack in Box #1

M8 x 20 mm 8 pcs
 M6 X 70 4 pcs
 M6 X 40 2 pcs
 Washer 8 pcs
 32 mm Screw - 8 pcs
 5 mm Allen Key 1 pc
 4 mm Allen Key 1 pc

 32 mm Screw - 20 pcs
 (wrapped in separate Plastic bag)
 Optional Slats Box

Box # 2


2 pcs. Bed Side rails
 1 pc Slat support

Box # 1

1 pc. Headboard
 1 pc. Footboard
 4 pcs. Bored Slat
 4 pcs. Support Leg

Box # 3

Optional Slats
 10 pcs. Slats



A complete assembled view of a Conventional Bed

Bed Assembly Instructions

MODERN BED

Step 1

Fix side rails to head board as shown with the M8 x 20 mm bolts and washers.
Fix foot board to side rails as shown using the M8 x 20 mm bolts and washers.

Step 2

Place the slats, slat supports and legs as shown using the M6 x 70 mm bolts and barrel nuts provided to secure the support legs to the slats and slats support. Use the two M6 x 40mm bolts to attach the second outer slat to the slat support.
After tightening all the bolts, screw the slats in place on to the side rails with the wood screws provided as shown.

