

850/050

Size of Mattress and Foundation

The length and width of the upper bunk TWIN mattress and foundation are as follows:

Length
74"-75"

Width
37 1/2"- 38 1/2"

Thickness
9 1/2" max

You must use only this size mattress.

Ensure thickness of mattress and foundation combined does not exceed 9 1/2" and that the mattress is at least 5" below upper edge of guardrails.

This Bunk Bed uses a slat kit for mattress foundation.



SAFETY WARNINGS



- (1) Follow the information on the warnings appearing on the upper bunk end structure and on the carton. Do not remove warning label from bed
- (2) Always use the recommended size mattress or mattress support, or both, to help prevent the likelihood of entrapment or falls
- (3) Surface of mattress must be at least 5 in. (127mm) below the upper edge of guardrails.
- (4) Do not allow children under 6 years of age to use the upper bunk.
- (5) Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight
- (6) Do not allow horseplay on or under the bed and prohibit jumping on the bed
- (7) Always use ladder for entering or leaving upper bunk.
- (8) Do not use substitute parts. Contact the manufacturer for replacement parts.
- (9) Use of a night light may provide added safety precaution for a child using the upper bunk
- (10) Always use guardrails on both long sides of the upper bunk. If the Bunk bed is place next to wall, the guardrail that runs the full length of the bed must be placed against the wall to prevent entrapment between the bed and the wall.
- (11) The use of water or sleep flotation mattress is prohibited
- (12) Prohibit more than one person on upper bunk.
- (13) **STRANGULATION HAZARD** : Never attach or hang items to any part of the Loft Bed that are not designed for use with the bed; for example, but not limited to, hooks, belts and jump ropes.
- (14) Keep these instructions for future reference.

850 BUNK BED

ASSEMBLY INSTRUCTIONS

Before assembling your Bunk Bed, please read through these instructions carefully, familiarizing yourself with the different parts.



A M6 X 90mm
ALLEN BOLT - 22 pcs



B M6 X 70mm
ALLEN BOLT - 24 pcs



C M6 X 60mm
ALLEN BOLT - 8 pcs




D M6 X 30mm
ALLEN BOLT - 24 pcs



E M6 X 16mm
CROSS DOWEL - 30 pcs




F WOOD SCREW 5/8" - 2 pcs



G METAL PIN - 4 pcs



H ALLEN KEY - 1 pcs



BED OPTION #2 :
SLATS - 4 PCS x 2 SETS

BED OPTION #1 :
SLATS - 13 PCS x 2 SETS

PARTS LIST

BOX 1 OF 3


- 1 LEFT UPPER FRONT POST ----- 2 PCS
- 2 RIGHT UPPER BACK POST ----- 1 PC
- 3 LEFT UPPER BACK POST ----- 1 PC
- 4 LEFT LOWER FRONT POST ----- 2 PCS
- 5 RIGHT LOWER BACK POST ----- 2 PCS
- 6 TOP RAIL ----- 4 PCS
- 7 MID RAIL ----- 4 PCS
- 8 BOTTOM RAIL ----- 4 PCS

BOX 2 OF 3

- 9 UPPER FRONT SIDE RAIL ----- 1 PCS
- 10 UPPER BACK SIDE RAIL ----- 1 PCS
- 11 LOWER FRONT/BACK SIDE RAIL ----- 2 PCS
- 12 BACK GUARD RAIL ----- 2 PCS
- 13 FRONT GUARD RAIL ----- 2 PCS
- 14 GUARD RAIL SUPPORT ----- 4 PC
- 15 LONG LADDER RAIL ----- 2 PC
- 16 LADDER STEP ----- 4 PCS


BOX 3 OF 3

- OPTION 1 ----- 14 PCS x 2 SETS
- 17 SLATS ----- 14 PCS x 2 SETS
- BOX 3 OF 3
- OPTION 2 ----- 4 PCS x 2 SETS
- 17 SLATS ----- 4 PCS x 2 SETS




STEP 1

Attach Top Rail(6), Mid Rail(7) and Bottom Rail (8) to the Left Upper Front Post (1) and Left Upper Back Post (2) as shown below. Using Allen Bolt (B) tighten with Allen Key (H).




STEP 2

Attach Top Rail(6), Mid Rail(7) and Bottom Rail (8) to the Right Upper Front Post (3) and Right Upper Back Post (1) as shown below. Using Allen Bolt (B) tighten with Allen Key (H).




STEP 3

Attach Front Side Rail(9), Back Side Rail(10) and Back Guard Rail(12) to the Left, Right Upper Panel assemblies as shown below. Using Allen Bolt (A) and Cross Dowel (E). Tighten with Allen Key(H).




STEP 4

Attach Front Guard Rail (13) to the Left, Right Upper Panel assemblies as shown below. Using Allen Bolt (A) and Cross Dowel (E). Tighten with Allen Key(I).



STEP 5


Attach Top Rail(6), Mid Rail(7) and Bottom Rail (8) to the Left Lower Front Post (4) and Left Lower Back Post (5) as shown below. Using Allen Bolt (B) tighten with Allen Key (H). Repeat the other.



- ASSEMBLY
- WRENCH (M 2.2mm)
- Allen Key (H)

STEP 6


Attach Front Side Rail (11), Back Side Rail(10) to the Left, Right Lower Panel assemblies as shown below. Using Allen Bolt (A) and Cross Dowel (E). Tighten with Allen Key(H).



- ASSEMBLY
- WRENCH (M 2.2mm)
- Cross Dowel (E)
- Allen Key (H)

STEP 7


Lay the Twin slat kit (17) onto the Bed, and fix in place using wood screws provided in the slat kit box. FOR SLAT KIT ASSEMBLY follow assembly instructions included with slat kit.



- WRENCH (M 2.2mm)
- Head Screw (F)

STEP 8


Insert Metal Pin (G) into the holes in top of the Lower Panel. Lift the Upper Bed onto the Lower Panel as shown, and fit the metal pins into the holes in the bottom of the upper Bed.



- ASSEMBLY
- Metal Pin (G)



STEP 9

Attach Ladder steps (16) to the Long ladder rail (15) as shown below. Using Allen Bolt (B) and Cross Dowel (E), tighten with Allen Key (H).



STEP 10

Install Ladder assemblies to the Bunk assemblies as shown below. Using Wood screw (F), Tighten with Phillips head screwdriver.



Congratulations !

Your 850 bunk bed is now ready for use. We recommend that you recheck that all screws are tightened, and that all parts are secure before use and periodically to ensure safety.